


NRG-IL125/150/200

Constant Pressure ,Variable-Volume, Inline Damper

Installation and Maintenance Manual

The EMC Directive
2014/30/EU
The Low Voltage
directive
2014/35/EU



1.0 INTRODUCTION

The three motorised inline damper models are designed for installation with Nuaire's range of Ecosmart Constant Pressure Variable Volume extract fans.

The units incorporate a fixed damper to set the trickle ventilation flow rate and a wax type 230V driven actuator to increase the flow rate to boost on demand.


Units are rectangular in section, manufactured from pre-galvanised steel and designed to match duct sizes of 125mm, 150mm and 200mm.

1.1 CODE DESCRIPTION

Code	Description	Weight
NRG-IL125	Inline, Constant Pressure Damper with Ø125mm Spigots	2kg
NRG-IL150	Inline, Constant Pressure Damper with Ø150mm Spigots	2.5kg
NRG-IL200	Inline, Constant Pressure Damper with Ø200mm Spigots	2.5kg

2.0 DIMENSIONS

Fig 1: Dimensions



Code	A	B	C	D	E
NRG-IL125	50	300	125	178	178
NRG-IL150	50	300	150	178	178
NRG-IL200	50	400	200	225	225

3.0 HANDLING

Handle the units carefully to avoid damage and distortion to moving parts.

4.0 PERFORMANCE DETAIL

Fig 2: Resistance of NRG-IL125




Fig 3: Resistance of NRG-IL150





Fig 4: Resistance of NRG-IL200



4.1 ACOUSTIC INFORMATION

Lw	Position 1	Position 2	Position 3	Position 4
100Pa	30	30.3	32.2	33.3
130Pa	33.5	32.8	36	37.1
150Pa	37.1	37.3	-	38.6

5.0 INSTALLATION

The installation must be carried out by suitably qualified and competent personnel in accordance with the appropriate authority and in conformance with all statutory and governing regulations i.e. IEE, CIBSE, COHSE, HVCA etc.

5.1 MECHANICAL INSTALLATION

The unit can be mounted in any attitude giving due consideration to the accessibility of the access door to complete the electrical connection, set up the damper during commissioning and future maintenance.

A full size access panel is fitted to one side to facilitate electrical connection and damper setting.


The unit should be coupled directly to ductwork of matching spigot diameter and installed behind a ceiling or in a service void and remote from any areas from which it could be subjected to water spray.

5.2 ELECTRICAL INSTALLATION

The damper is activated by a 230V mains signal, this signal can be derived from any switching source i.e. light switch, mains PIR, mains rated thermostat, humidistat etc.

Offer the mains cable via the cable grommet provided connecting Live (L), Neutral (N) and Earth (E) to the appropriate terminals.


Fig 5: Wiring Diagram with a Third-Party Switching Device e.g. Light Switch, PIR, Humidistat etc,



5.3 SETTING THE DAMPERS

Trickle ventilation; minimum trickle rate is pre set by the free area cut around the motorised damper. To increase the trickle ventilation rate remove one of motorised damper cheek plates (A1), to further increase the trickle rate remove the second cheek plate (A2).

Fig 6: Unit With Access Panel Removed, Showing electrical connection and damper setting positions



Boost ventilation rate is set by adjusting the setting screw (B), with flow meter connected to duct work and motorised damper activated (by switching on power to unit) adjust the damper position whilst monitoring flow meter until desired boost airflow rate is achieved.

6.0 MAINTENANCE

Maintenance intervals will vary according to the level of airborne contaminant to which the unit is exposed; check three months after commissioning and twelve monthly thereafter.

There are no parts requiring lubrication.

Isolate the mains supply, remove the access cover and clean out any dust deposits. Check the security of all components and wire terminations - do not adjust the damper setting screw.

To clean the dampers and internal chamber it will be necessary to remove the unit from the system and access through the inlet/outlet spigots, mark the position of the setting screw (B) and ensure the position is set correctly upon reinstatement.

There are no recommended spares, should the product malfunction then it will require total replacement. Order quoting all the details from the product rating plate.

7.0 WARRANTY

The 3 year warranty starts from the day of delivery and includes parts and labour for the first year. The remaining 2 years covers replacement parts only.

This warranty is void if the equipment is modified without authorisation, is incorrectly applied, misused, disassembled, or not installed, commissioned and maintained in accordance with the details contained in this manual and general good practice.

The product warranty applies to the UK mainland and in accordance with Clause 14 of our Conditions of Sale.

Customers purchasing from outside of the UK should contact Nuaire International Sales office for further details.

8.0 AFTER SALES AND REPLACEMENT PARTS

For technical assistance or further product information, including spare parts and replacement components, please contact the After Sales Department.

If ordering spares please quote the serial number of the unit together with the part number, if the part number is not known please give a full description of the part required. The serial number will be found on the identification plate attached to the unit casing.

Telephone 02920 858 400
aftersales@nuaire.co.uk

Technical or commercial considerations may, from time to time, make it necessary to alter the design, performance and dimensions of equipment and the right is reserved to make such changes without prior notice.