

MRXBOX95-3SWITCH

3 Speed Switch

Installation and Maintenance

1.0 Introduction

The MRXBOX95-3SWITCH has been designed to be installed to speed control a fan that has three variable speed settings.

2.0 Installation

To fix the switch in position remove the front fascia by inserting a terminal screwdriver into the apertures along the bottom edge and prize open gently, the fixing points on the back plate can then be accessed to allow secure fitting to a standard single gang pattress. The front fascia can then be refitted.

3.0 Wiring

Wiring should only be carried out by a qualified electrician.

Refer to the installation guide of the unit to which the switch is to be connected for any specific installation instructions and fuse rating. Typical wiring diagrams are shown in the figures below.

Figure 1. Switch Dimensions




Figure 2. Unit Only




Figure 3. Unit Serving One Bathroom





Figure 4. Unit Serving Two Bathrooms



4.0 After Sales Enquiries

For technical assistance or further product information, including spare parts and replacement components, please contact the After Sales Department.

IMPORTANT

Isolate the mains power before carrying out any electrical wiring.

Telephone 02920 858 400
aftersales@nuaire.co.uk