Installation Guide


SmarTwin ST-MAN Manual Switch



NuAire Limited, Western Industrial Estate, Caerphilly, Mid Glamorgan. CF83 1XH. United Kingdom. Tel: 01222 885911 Fax: 01222 887033 Email: info@nuaire.co.uk

Leaflet 670939

DECEMBER 1998



SS-MAN Manual Switch

This device is used to manually override the fan control for effective on / off operation.

Designed to be used with the SmarTwin range of supply and extract fans the switch is supplied with a pre-plugged 10m length of communications cable.

The switch operates on Low Voltage and is powered from the fan control module.

Fan Fail Indication

A green status LED indicateas that the fan is operating correctly.


Status LED change to red indicates that there is a fault at the fan.

Communications cable

A 10m length of Safe Extra Low Voltage communications cable (SELV) is supplied with the sensor.

1

Connection of the ST-MAN Manual Switch to the Control module located at the fan.



NU/AIRE

Western Industrial Estate, Caerphilly, CF83 1XH, United Kingdom. Telephone: 01222 885911 Facsimile: 01222 887033, Email: info@nuaire.co.uk

Leaflet No. 670939

Technical or commercial considerations may, from time to time, make it necessary to alter the design, performance and dimensions of equipment and the right is reserved to make such changes without prior notice.